Interface Pads and Pad Conversions

Detail Sanders Tear Drop and Triangle Part No. Diameter

Tear Drop

Triangle

53970

53972

Sanders "O" Style Pad

53998

For 11" Dia.

Part No. Diameter

11"

Dynafoam Interface Pads

For Random Orbital Sanders

 \bigcirc

()

 \bigcirc

Non-Vac and Vacuum Orbitals

Part No. Diameter

3-1/2"

3"

5"

6"

8"

53974


53976

53978

53980

53982

- Soft foam increases conformability allowing operator to easily follow contours. Converts standard pad into a fine finishing and finessing pad!
- Interface pad easily contours to most surfaces.
- Attaches between hook-face sanding pad and hook 'n loop abrasive.



For Dynafine®



For Board Sanders

Dynaline and Dynabug®

Part No.	Size and Tool For Use With	
53984	2-3/4" x 11" Tool: Dynaline	
53986	2-3/4" x 8" Tool: Dynaline	• • • •
53988	3-2/3" x 7" Tools: Dynaline/Dynabug®	· · · · · ·

PSA-To-Hook Pad Conversions

• Thin sticky-back sheet adheres to current PSA pad and accepts hook 'n loop abrasives.

For Random Orbital Sanders

Non-Vac and Vacuum Orbitals

Part No.	Diamet	er
53975	3"	0
53977	3-1/2"	\bigcirc
53979	5"	
53981	6"	
53983	8"	

For Dynafine® Detail Sanders

Tear Drop and Triangle

	-	-
Part No.	Diameter	
53971	Tear Drop	\bigcirc
53973	Triangle	\bigtriangleup

 $igstyle \mathsf{Peel-off}$ liner with sticky-back adheres to operator's current vinyl-face pad.

Hook-face material for accepting standard hook 'n loop abrasives.

For Board Sanders

Dynaline and Dynabug®

Part No.	Size and Tool For Use With	
53985	2-3/4" x 11" Tool: Dynaline	
53987	2-3/4" x 8" Tool: Dynaline	• • • •
53989	3-2/3" x 7" Tools: Dynaline/Dynabug®	•••••

Hook-To-PSA Pad Conversions

• Thin velcro-backed sheet attaches to standard hook-face pad and accepts PSA abrasives.

Non-Vacuum and Vacuum Orbitals

Part No.	Diameter	
53992	5"	•••
53993	6"	



¥ Loop material attaches to standard hook-face sanding pad.

Premium vinyl-face for stick-on abrasives. 🙏