

# Arbors

*Use to Mount Abrasive Wheels, Discs, Pneumatic Wheels, etc.*

**Use Dynabrade arbors to mount abrasive wheels, discs, stars and other accessories to male spindle tools**

For use with many Dynabrade and other manufacturers' portable tools and bench grinders. Mount abrasive wheels, discs, pneumatic wheels, sanding stars and other accessories to 3/8"-24, 1/2"-20 or 5/8"-11 male spindle tools by using the combination of spacers and flanges that suits your application.

**Part Number 13074**

**Arbor Kit**

- Mounts to 3/8"-24, 1/2"-20 AND 5/8"-11 male spindle sizes; also accepts any Dynacushion® or accessory which has 5/8" bore from 1/2" to 3" wide in 1/2" increments.



**NOTE:** Speed of tool must not exceed maximum operating speed of accessory

Tool Spindle	Part Number	Image	Arbor Thread	Arbor Bore	Wheel Width
3/8"-24 Male	13061		-	5/8" 1"	Up to 2-1/2"
	13074		-	5/8" 1"	Up to 3"
1/2"-20 Male	13014		-	14 mm	Up to 51 mm
	13016		-	1/2"	Up to 2"
	13017		-	5/8"	Up to 2"
	13071		-	5/8" 1"	Up to 3"
	13074		-	5/8" 1"	Up to 3"
	13015		5/8"-11 Male	-	3-1/2"
	5/8"-11 Male	13073		-	5/8" 1"
13074			-	5/8" 1"	Up to 3"