200

ACCESSORIES

Contact Wheels and Assemblies (Cont'd)

Keep your Belt Tools Running at Maximum Efficiency

Dynafile® II Contact Arm Assemblies (Cont'd)

*Assembly comes standard with contact arm shown

Dynanic	io II dollitiot vi ili voodilibiloo (dolli ii)					Assembly comes standard with contact and shown						
Contact Arm Part Number		Wheel Assembly Part Number		Ц	Wheel P/N	Wheel Dia.	Wheel Width	Wheel I.D.	Face Surface	Material		
11329		11078*		-	11077	5/8"	3/8"	3/8"	Crowned	70 Duro Rubber		
11330		11072*	•		11071	7/16"	1/8"	3/8"	Crowned	Brass		
		11074			11073	5/8"	1/8"	3/8"	Crowned	70 Duro Rubber		
11337		11076*	_	-	11075	7/16"	3/8"	3/8"	Crowned	Steel		
		11068		=	11067	5/16"	3/8"	1/4"	Crowned	Steel		
11350		11352*	= _		11353	5/16"	5/8"	1/4"	Crowned	Steel		
11360		11078*	@		11077	5/8"	3/8"	3/8"	Crowned	70 Duro Rubber		
11286		11078*		_	11077	5/8"	3/8"	3/8"	Crowned	70 Duro Rubber		
11287		11282*	6	_	11281	3/4"	5/8"	3/8"	Crowned	70 Duro Rubber		
11314		11066*	=	9	11065	5/16"	1/8"	1/4"	Flat	Steel		
11320		11078*	0		11077	5/8"	3/8"	3/8"	Crowned	70 Duro Rubber		
11321		11070*		=	11069	7/16"	3/8"	1/4"	Crowned	70 Duro Rubber		
		11068			11067	5/16"	3/8"	1/4"	Crowned	Steel		
		11076		=	11075	7/16"	3/8"	3/8"	Crowned	Steel		
11322		11090*	@		11077	5/8"	3/8"	3/8"	Crowned	70 Duro Rubber		