Arbors and Threaded Mandrels

Arbors: Use to Mount Abrasive Wheels, Discs, Pneumatic Wheels, etc.

Use Dynabrade arbors to mount abrasive wheels, discs, stars and other accessories to male spindle tools

For use with many Dynabrade and other manufacturers' portable tools and bench grinders. Mount abrasive wheels, discs, pneumatic wheels, sanding stars and other accessories to 3/8"-24, 1/2"-20 or 5/8"-11 male spindle tools by using the combination of spacers and flanges that suits your application.

Part Number 13074 Arbor Kit

 Mounts to 3/8"-24, 1/2"-20 AND 5/8"-11 male spindle sizes; also accepts any Dynacushion® or accessory which has 5/8" bore from 1/2" to 3" wide in 1/2" increments.





NOTE: Speed of tool must not exceed maximum operating speed of accessory

Tool Spindle	Part Number	Arbor Thread	Arbor Bore	Wheel Width
3/8"-24 Male	13061	-	5/8" 1"	Up to 2-1/2"
	13074	-	5/8" 1"	Up to 3"
1/2"-20 Male	13014	-	14 mm	Up to 51 mm
	13016	-	1/2"	Up to 2"
	13017	-	5/8"	Up to 2"
	13071	-	5/8" 1"	Up to 3"
	13074	-	5/8" 1"	Up to 3"
	13015	5/8"-11 Male	-	3-1/2"
5/8"-11 Male	13073	-	5/8" 1"	Up to 3"
	13074	-	5/8" 1"	Up to 3"

Threaded Mandrels

Use with Dynabrade DynaStrip Discs

Part Number 95722

• 1/4" dia. with 1/4" shaft.



Part Number 95749

 1/2" dia. with 1/4" shaft.



"Universal" Shank Arbor

Part Number 12995

• Arbor: 1/4" shaft.

Part Number 12977

• Arbor: 6 mm shaft.

Part Number 12980

Arbor: 3/8"-24 female thread.

