## **Contact Wheels and Assemblies (Cont'd)**

## **Keep Your Belt Tools Running at Maximum Efficiency**

## Dynafile® II Contact Arm Assemblies (Cont'd) \*Assembly comes standard with Contact Arm shown **Contact Arm** Wheel Assembly Wheel Wheel Wheel Wheel Face Material Part No. Part No. Part No. Width **Surface** Dia. I.D. 0 70 Duro Rubber 11074\* 11073 5/8" 1/8" 3/8" Crowned 11202 11072 11071 7/16" 1/8" 3/8" Crowned Brass 11203 11078\* 11077 5/8" 3/8" 3/8" Crowned 70 Duro Rubber Round 1" 3/8" 3/8" 11080\* 11079 70 Duro Rubber Radiused 11204 11078 11077 5/8" 3/8" 3/8" 70 Duro Rubber Crowned 90 Duro 11086 11085 1" 3/8" 3/8" V-Shaped Urethane 3/4" 11206 11282\* 11281 5/8" 3/8" Crowned 70 Duro Rubber 11220 11352\* 11353 5/16" 5/8" 1/4" Crowned Steel 11086\* 11085 1" 3/8" 3/8" 90 Duro Rubber V-Shaped 11280 11078 11077 5/8" 3/8" 3/8" 70 Duro Rubber Crowned Round 11080 11079 1" 3/8" 3/8" 70 Duro Rubber Radiused 11286 11078\* 11077 5/8" 3/8" 3/8" Crowned 70 Duro Rubber 3/4" 3/8" 11287 11282\* 11281 5/8" Crowned 70 Duro Rubber 1/4" 11332\* 11333 3/8" 3/16" Crowned Steel 11300 11342 11343 5/16" 3/8" 3/16" Crowned 50 Duro Rubber 11068\* 11067 5/16" 3/8" 1/4" Steel Crowned 11301 11070 11069 7/16" 3/8" 1/4" 70 Duro Rubber Crowned 11078\* 11077 5/8" 3/8" 11304 3/8" Crowned 70 Duro Rubber .

**AIR TOOL ACCESSORIES**